

'SimTek' ECU Range

Enhanced Feature External Connections

E1S96 Fw Ver 1.5.0

ALS Enable	B9
Map Select	D16
Launch Enable	B10
H2O Spray Out	D6

B is the 12 way plug. D is the 26 way plug.

E1S97 Fw Ver 1.5.0

ALS Enable	C7
Map Select	C11
Launch Enable	C9
H2O Spray Out	C15

C is the 16 way plug.

E1S99 Fw Ver 1.5.0

ALS Enable	B21
Map Select	B1
Launch Enable	B29
H2O Spray Out	C10
H2O Spray In	A10

A is the Blue plug. B is the Grey plug. C is the Black plug.

E1S02 Fw Ver 0.0.2

ALS Enable	A17
Map Select	A9
Launch Enable	A8
H2O Spray Out	E11
H2O Spray In	B12

A is the 22 way plug. B is the 28 way plug. E is the 31 way plug

Note : The E1S96 & E1S97 currently have no 'H2O Spray In'. This could be provided if required, but would require a firmware upgrade.